



Quick Start Guide*

* See owner's manual for complete instructions and important safety information before using this product.

Step 1



Place Inner Pot into the unit.

Step 2



Add Ingredients.

Step 3



Place Lid on Cooker with Handle and Recessed Valve pointed to the "10:00 o'clock" position. Rotate Lid counter-clockwise until you feel a click.

Step 4



Rotate Pressure Valve to the Lock position.

Step 5



Follow your recipe for correct cook time.

Step 6



For easiest cleanup, wash Power Pressure Cooker parts immediately after cooking. Place dishwasher-safe parts on the top rack only.

Wash All Components Before First Use